


FITTING INSTRUCTION



Clamp mark in acc. with		Cables joining
ISO	PN	
1	L	Left directional lights
2	+	Rear fog lights
3	31	Ground
4	R	Right directional lights
5	58R	Right side parking lights
6	54	Stoplights
7	58L	Left side parking lights

This towing hitch is designed to assembly in following cars:
MITSUBISHI OUTLANDER, PEUGEOT 4007, CITROEN C-CROSSER
 produced since 2007, catalogue no. **Z38A** and is prepared to tow trailers
 max total weight **2000 kg** and max vertical load **100 kg**.

Torque settings for nuts and bolts (8,8):	
M 8 - 25 Nm	M 10 - 55 Nm
M 12 - 85 Nm	M 14 - 135 Nm

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be installing in points described by a car producer.

The instruction of the assembly

- Underneath a car disassemble spare wheel unit and unfasten a muffler from last rubber handle.
 - On the right side, to chassis member fix trough holes A right bracket (pos. 4) with right fish-plate (pos. 5) using bolts M10x1,25x40mm (pos. 10) as shown on figure 1. Next fix fish-plate from side using two bolts M10x1,25x40mm (pos. 10).
 - In bumper cut out fragment (in axis) according to figure 2.
 - Put main bar of the towing hitch (pos. 1) to car's chassis and fix as shown in figure 1:
 - to left chassis member through holes B using bolts M10x1,25x40mm (pos. 10) with left fish-plate (pos. 6). Fish-plate fix from side using two bolts M10x1,25x40mm (pos. 10).
 - on the right side to already mounted right bracket (pos. 4) using bolts M12x40mm (pos. 9)
 - Fix body of the automat (pos. 8) and the socket plate (pos. 7) using bolts M12x25mm (pos. 4) from accessories. Place tow-ball (pos. 2) according to supplied instruction.
- IMPORTANT! See note on page 1 of this instruction.**
- Reassemble spare wheel unit and attach a muffler.
 - Tighten all bolts according to the torque shown in the table.
 - Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station).
 - Complete paint layer damaged during installation.




Fig. 2 Bumper's cut out

















NOTE

After install the towing hitch you should get adequate note in registration book (at authorised service station).The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.

Towing hitch accessories:

Pos. 1	Main bar  PCS.: 1	Pos. 5	Right fish-plate  PCS.: 1	Pos. 11	Plain washer ø12mm  PCS.: 7
		Pos. 6	Left fish-plate  PCS.: 1	Pos. 12	Plain washer ø10mm  PCS.: 10
Pos. 2	Tow ball  PCS.: 1	Pos. 7	Bolt 8,8 B M12x25mm  PCS.: 4	Pos. 13	Spring washer ø12mm  PCS.: 7
Pos. 3	Socket plate  PCS.: 1	Pos. 8	Body of the automat  PCS.: 1	Pos. 14	Spring washer ø10mm  PCS.: 10
Pos. 4	Right bracket  PCS.: 1	Pos. 9	Bolt 8,8 B M12x40mm  PCS.: 3	Pos. 15	Nut 8 B M12  PCS.: 3
		Pos. 10	Bolt 8,8 B M10x1,25x40mm  PCS.: 10	Pos. 16	Ball cover  PCS.: 1



PPUH AUTO-HAK S.J.

Produkcja Haków Holowniczych
Henryk & Zbigniew Nejman
76-200 SŁUPSK ul. Słoneczna 16K
tel/fax (059) 8-414-414; 8-414-413
E-mail: office@autohak.com.pl
www.autohak.com.pl

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **Z38A**

Designed for:

MITSUBISHI OUTLANDER

PEUGEOT 4007

CITROEN C-CROSSER

produced since 2007

Technical data:

D-value: 11,0 kN

maximum trailer weight: **2000 kg**

maximum vertical cup load: **100 kg**

Approval number according to Directive 94/20/EC: e20*94/20*0340*00

NOTE!

With installed tow ball opening of bottom part of boot door is impossible! Do not open it when tow ball is installed! Before open dismount a tow ball. Additionally stick the supplied information label in visible place, please.

Foreword

This towing hitch is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$